



One Step Multi-Bead Plus

PANTHER EAST



Start Up

1. Make sure batteries are fully charged. If battery is not fully charged, charge until display confirms that it is fully charged. Plug charger into electrical outlet. Connect the battery to the charger (for MBA: black connector to black connector, red connector to red connector; for MBA Plus: gray connecting terminal from charger to gray terminal on battery). Make sure 2/6/10 button is depressed to activate the charging process. The indicator lights on the charger will display the status of the battery.
2. Install fully charged battery into battery compartment and connect the terminals.
3. Test the MBA by depressing the trigger switch. Make sure all plungers are functional. To activate the return, pull firmly on the return handle. To test the MBA Plus turn the "Dispense/Retract" dial to the "dispense" position and depress the trigger switch. Make sure all plungers are functional. To activate the return, turn "Dispense/Retract" dial to "Retract" position; the plungers will retract automatically.
4. Prepare Millennium One Step™ adhesive cartridges by removing the molded tips from the threaded mixing head, and attach the provided One Step™ mixing nozzle.
5. Load cartridges, and ensure that each cartridge is firmly in place.
6. Position applicator where adhesive is to be dispensed and the insulation or membrane is to be installed.
7. Begin dispensing adhesive by depressing trigger switch, and pull applicator at a rate which will put down adhesive beads 1/4" to 1/2" (0.6cm to 1.3cm) wide.
8. When finished dispensing cartridges in their entirety, pull return handle until plungers have completely retracted. On the MBA Plus set the "Dispense/Retract" dial to "retract" position. Remove empty cartridges.



Features

MBA applies 4 beads of adhesive simultaneously

MBA Plus has 13 cartridge capacity

Battery powered

Low maintenance

Fastest method of installing rigid insulation

Benefits

Install up to 6 squares in less than 2 minutes

Install adhesive from 12" o.c. up to full coverage

No cords or generators required

No work delays due to equipment failure

Lower installed cost

Safety

Protective equipment such as safety glasses and protective gloves must be worn when operating or services the MBA and MBA Plus applicators.

Under no circumstances should any acid or corrosive chemicals be used in the machines. The electrical circuitry is not of explosion proof design and should not be used in any environment requiring such a design.

The MBA and MBA Plus applicator should never be actuated when the outlet tip of the adhesive cartridge(s) is blocked or restricted by cured adhesive, any object or some part of the body.

Prior to working with this or any product consult product label and Material Safety Data Sheet (MSDS) for necessary health and safety precautions.

215.335.6797

www.PANTHEREAST.com

